


# Start/Stop funktion ved Fabriksindstilling


Default Mode (NC) = STOP

Gen 2



- GND
- +10 V
- Din 1

Gen 3



- GND
- +10 V
- IO1